BRIGMTON

BCC-10

CÁMARA PARA AUTOMÓVIL

Manual de Instrucciones

FUNCIONES Y CONTROLES



1. Entrada USB
2. Salida AV
3. Entrada tarjetas SD/MMC
4. Altavoz
5. Entrada para soporte
6. Micrófono
7. Compartimento de batería
8. Cámara
9. Sensores de visión nocturna
10. ON/OFF
11. Botón de grabación
12. Pantalla LCD 2,4”
13. Botón Menú
14. Botón Down
15. Botón Up
16. Botón de Modo

FUNCIONAMIENTO

El dispositivo puede funcionar alimentado de dos formas:

A) A través de la batería recargable. Coloque la batería en su compartimento y presione el botón de encendido durante 1 segundo. Para apagar presione durante 2 segundos. Para cargar la batería conecte el cable suministrado a la toma de mechero de su vehículo.

B) Con alimentación directa desde la toma de mechero. De esta forma la cámara se activará cuando arranque su vehículo y detendrá la grabación cuando desconecte la llave.

GRABACIÓN
La cámara entrará en el modo de grabación cuando la encienda. Al comenzar parpadeará el indicador en rojo. El archivo de grabación se guardará en la tarjeta. Para detener la grabación, pulse el botón de grabación.

MODOS DE CÁMARA
Presione el botón Mode para entrar en el modo fotos. Presione el botón REC (O) para tomar una foto.

FUNCIÓN DE ENFOQUE MANUAL
En el modo de vídeo o foto, presione ARRIBA/ABAJO y se mostrará el icono de enfoque. Pulse de nuevo ARRIBA/ABAJO para seleccionar el enfoque deseado. Podrá elegir de 1x ~ 8x.

FUNCIÓN DE VISIÓN NOCTURNA
Pulse el botón Menú y elija la opción visión nocturna. El dispositivo entrará en el modo de visión nocturna. P=ara salir de este modo seleccione “Off”.

VISIÓN Y BORRADO
Presione el botón MODE dos veces para entrar en modo de vista previa. Pulse Arriba o Abajo para seleccionar el archivo que desea ver. Si se trata de archivos de vídeo, puede reproducir o pausar pulsando el botón del REC y detener presionando el botón Mode. Si desea borrar un archivo, pulse el botón Menú para entrar en el modo de borrado, y luego, seleccione uno o todos los archivos y confirme para suprimir con el botón Menú. Puede seleccionar una presentación de diapositivas, proteger archivo, el modo de miniaturas y el volumen (1-8) en el modo de vista previa.

AJUSTE DE FUNCIONES
Presione el botón Menú en el modo Vídeo o modo de Fotos para entrar en la interfaz de configuración. Seleccione la función a cambiar y confirme por el botón Menú. Seleccione la opción con los botones arriba/abajo. Pulse el botón REC para salir.

FUNCIONES

A. VIDEO MODE
1. Tamaño: VGA 640*480),720*480,1280*720,1280*960
2. Tiempo: Off/Date Only/Date &Time
3. Detección de movimiento: Off/On
4. Tiempo de grabación: Off/ 1Min/2Min /3Min /4Min /5Min/10Min/15Min
5. Audio: On/Off
6. Modo nocturno: Off/On

B. CAMERA MODE:
1. Tiempo: Off/Date Only/Date &Time
2. Beep: Off/On

C. SETTING-CONFIGURACIÓN: Pulse Menú y luego Mode para entrar en Configuración

1. Formato: Para formatear la tarjeta SD
2. Beep: Off/On
3. Idioma: Inglés, Frances, Alemán, Italiano, Español, Portugués, Chino, Ruso, Turco, Koreano.
4. Auto Off: 1Min/2Min/5Min/Off
5. System Reset
6. Light Frequency: 50Hz/60Hz
7. Salida TV: NTSC/PAL
8. Fecha
9. USB
10. Version

VISUALIZACIÓN EN TV
Conecte la salida AV a su televisor y entre en el modo de visión automático.

MODO USB
Conecte el dispositivo a su PC a través de un cable USB y aparecerá como unidad externa/extraíble. Selecciones los archivos a descargar en su PC.

NOTAS
1) Introduzca la tarjeta SD/MMC antes de grabar.
2) Puede seleccionar el tiempo de cada archivo de grabación de vídeo entre 3/5/10/15. Cuando la tarjeta esté llena, volverá a grabar sobre lo grabado y borrará lo grabado inicialmente de forma automática. Contará con 3 segundos de tiempo de pausa.
3) Use siempre el cargador suministrado, no lo cambie por otro sin consultar las especificaciones. Las características son 12V/24V a 5V.

ESPECIFICACIONES TÉCNICAS
1) Resolución de grabación: 640*480, 720*480, 1280*720, 1280*960 pixels.
2) Formato de vídeo: AVI
3) Duración de vídeo: 3/5/10/15 minutos.
4) Alimentación: Batería recargable BL-5C o adapatdor 5V.
5) Soporta tarjetas SD/MMC hasta 32 GB
6) Micrófono incorporado

Nota: las especificaciones pueden cambiar sin previo aviso.

I.R.P., S.L.
SANTA CLARA DE CUBA NAVE 5
SEVILLA
ESPAÑA

DECLARACIÓN DE CONFORMIDAD

I.R.P., S.L. declara bajo su responsabilidad que el aparato indicado cumple los requisitos de las siguientes directivas:

DIRECTIVAS EMC

Descripción del aparato:

Modelo BRIGMTON **BCC-10**
Cámara de vídeo

Importador: I.R.P., S.L.
Dirección: Avda. Santa Clara de Cuba 5, 41007, Sevilla.

BRIGMTON

BCC-10

CAR CAMERA

Instruction Manual

PRODUCT PICTURE AND FUNCTION



1. USB Port
2. AV-OUT Port
3. SD/MMC Card Slot
4. Speaker
5. Mount hole
6. Microphone
7. Battery cover
8. Lens
9. Night Lights
10. ON/OFF Power Switch
11. REC / Snap
12. 2.4 inch LCD
13. Menu
14. 15.Up /Down
16. Mode Button

OPERATIONS:

Two options of charging the DVR:

A) Charging by using rechargeable battery

DVR can be activated after it has been placed on the vehicle by pressing the Power Switch for 1 second and turn off by pressing it for 2 seconds.

Charging: connect with USB cable or car charger.

B) Connect with Car Charger

DVR will record automatically when the car starts, turn off and save the last file when the car stops.

RECORDING
DVR will enter into defaulted recording mode when turning it on, the working indicator blinks and indicates it is recording. The recording file is saved in the SD/MMC Card. To stop, press Recording Button or ending when car stops , the work indicator won`t blink.

CAMERA MODE
Turn on the DVR and press Mode Button to enter into Camera mode. To take photo by pressing Snap Button .

MANUAL FOCUS FUNCTION
In Camera or Recording mode, press UP/DOWN Button the screen will show focus icon them press UP/DOWN button to choose the focus needed, you can choose (1x~8x).

NIGHT VISION FUNCTION
Press Menu button then choose Night vision, DVR will enter Night vision status if you want to exit choose “off”.

PREVIEW AND DELETE
Turn on the DVR and press Mode Button twice to enter into Preview Mode. Press Up or Down to select the previewed file. If it is video file, it can play or pause by pressing REC Button, and stop by pressing Mode Button. If you want to delete it, press Menu Button to enter into delete mode, and then, select Single, All by Menu Button and Up/Down and confirm to delete the file by Menu Button. Also select Slide show, Protect file, Thumbnail mode and volume (from 1 to 8) under the Preview Mode.

SETTING THE FUNCTIONS:
Turn on the DVR and Press Menu Button under Video mode or Camera mode to enter into setting interface. Confirm by Menu Button and Select by Up/Down for the following setting. Press REC Button to exit.

A. VIDEO MODE
   1. Size: VGA(640*480),720*480,1280*720,1280*960.
   2. Time Stamp: Off/Date Only/Date &Time
   3. Motion Detect: Off/On
   4. Video Time: Off/ 1Min/2Min /3Min /4Min /5Min/10Min/15Min
   5. Audio: On/Off
   6. Night Mode: Off/On

B. CAMERA MODE
   1. Time Stamp: Off/Date Only/Date &Time
   2. Beep: Off/On

C. SETTING MODE

Whether under idle Mode, Press Menu Button and then press Mode Button to enter into Setup interface.

1. Format: Select it if you want to format the SD card.
2. Beep: Off/On

3. Language: Select English, French, Deutsch, Italian, Spanish, Portuguese, Chinese, Russian, Turkish, Korean.
4. Auto Off: 1Min/2Min/5Min/Off
5. System Reset: select [Cancel or Execute system] reset.
6. Light Frequency: 50Hz/60Hz
7. TV Output: NTSC/PAL
8. Date Input: Set correct recording date and time.
9. USB: PC Cam/Disk Drive
10. Version :Check software version

PREVIEW ON THE TV

Connect the AV port of DVR with the TV, and enter into the preview mode automatically. The operating steps are same as preview on the screen.

USB MODE

Connect DVR with computer by USB cable, [My computer] will occur removable disk, the file id stored at Removable Disk/DCIM/100DSCIM. At the moment, the file of the DVR can be downloaded to the computer.

NOTE:

1) Please insert the SD/MMC card before recording.
2) This DVR Records in cycle if you choose 3/5/10/15 minutes as storage time. When the storage medium is full, it will record from the beginning again and erase over the previously recorded material automatically. It will have 3 seconds pause time, and namely the contents in the 3 seconds will not record.
3) Because the DVR is DC5Vinput, please use the attached car charger. It has adaptor 12V/24V transfers to 5V already.

TECHNICAL SPECIFICATIONS

1. Recording resolution: 640*480,720*480,1280*720,1280*960. pixels
2. Video format: AVI
3. Repeat storage by section: 3/5/10/15 minutes
4. Power source: Built-in rechargeable battery or 5V Car Charger
5. Supports SD/MMC card up to 32GB
6. Microphone: can record sound

Features can change without notice

I.R.P., S.L.
SANTA CLARA DE CUBA NAVE 5
SEVILLA
ESPAÑA

DECLARATION OF CONFORMITY

I.R.P., SL declare under our responsibility that the equipment meets the requirements indicated in the following directives:

EMC DIRECTIVES

Description of apparatus:

BRIGMTON Model **BCC-10**
Car Camera

Importer: I.R.P., SL
Address: Avenida Santa Clara de Cuba 5, 41007, Sevilla.